

Netopia R3100-T v4.9.3

Easy Setup...

WAN Configuration...

System Configuration...

Utilities & Diagnostics...

Statistics & Logs...

Quick Menu...

Quick View...

Return/Enter to navigate quickly to a particular screen.
You always start from this main screen.

Quick Menu

Connection Profiles

Add Connection Profiles

Change Connection Profiles

Delete Connection Profiles

WAN Default Profile

ATMP/PPTP Default Profile

Scheduled Connections

Add Scheduled Connection

Change Scheduled Connection

Delete Scheduled Connection

Console Configuration

SNMP Setup

Line Configuration

Fr. Relay Config

Fr. Relay DLCI Config

Backup Config

TFTP

IP Setup

IP Address Serving Setup

IP Filter Sets

Static Routes

Network Address Translation

IPX Setup

IPX Filters & Filter Sets

This menu allows you to visit most configuration screens.

Network Address Translation

Add Public Range...
Show/Change Public Range...
Delete Public Range...

Add Map List...
Show/Change Map List...
Delete Map List...

Add Server List...
Show/Change Server List...
Delete Server List...

NAT Associations...

Return/Enter to select <among/between> ...
Return/Enter to configure IP Address redirection.

```
Network Address Translation
+-NAT Server List Name-+
+-----+
A| Easy-Servers |
S|               |
D|               |
|               |
A|               |
S|               |
D|               |
|               |
A|               |
S|               |
D|               |
|               |
A|               |
S|               |
D|               |
|               |
N|               |
|               |
+-----+
```

Up/Down Arrow Keys to select, ESC to dismiss, Return/Enter to Edit.

Show/Change NAT Server List

Server List Name:

Easy-Servers

Add Server...

Show/Change Server...

Delete Server...

Return/Enter goes to new screen.

Add NAT Server ("Easy-Servers")

Service...

Server Private IP Address:

Public IP Address:

Type	Port (s)
ftp	20 - 21
telnet	23
smtp	25
tftp	69
gopher	70
finger	79
www-http	80
pop2	109
pop3	110
snmp	161 - 162
timbuktu	407
pptp	1723
irc	6665 - 6669
Other...	

ADD NAT SERVER

CANCEL

Other Exported Port

First Port Number (1..65535): 24500

Last Port Number (1..65535): 24505

OK

CANCEL

Add NAT Server ("Easy-Servers")

Service...	24500 - 24505
Server Private IP Address:	192.168.1.131
Public IP Address:	64.7.

ADD NAT SERVER

CANCEL

Enter an IP address in decimal and dot form (xxx.xxx.xxx.xxx).